


6LE000051C






Vector

- ⒹⒺ Montageanleitung
- ⒻⒻⒺ Notice d'instructions
- ⒼⒹⒼ Mounting instructions
- ⒼⒹⒼ Montage instructie
- ⒹⒾⒻ Monteringsvejledning
- ⒻⒻⒺ Asennusohje
- ⒼⒹⒼ Montasjeanvisning
- ⒼⒹⒼ Monterings instruktioner
- ⒻⒻⒺ Istruzioni di montaggio
- ⒼⒹⒼ Instrucciones de montaje
- ⒻⒻⒺ Instruções de montagem
- ⒼⒹⒼ Montážní návod
- ⒼⒹⒼ Uputstvo za montažu



- ⒻⒻⒺ Upute za montažu
- ⒻⒻⒺ Szerelési útmutató
- ⒻⒻⒺ Montavimo instrukcija
- ⒻⒻⒺ Montāžas instrukcija
- ⒻⒻⒺ Instrukcja montażowa
- ⒻⒻⒺ Instrucțiuni de montare
- ⒻⒻⒺ Návod na montáž
- ⒻⒻⒺ Инструкција по монтажу
- ⒻⒻⒺ Инструкции за монтаж
- ⒻⒻⒺ Οδηγίες χώνευσης
- ⒻⒻⒺ Navodilo za montažo
- ⒻⒻⒺ Paigaldusjuhised
- ⒻⒻⒺ Leiðbeiningar
- ⒻⒻⒺ دليل التركيب



EN 60670-24 (PD)



	VE103	VE106	VE110	VE112	VE212	VE312	VE412	VE118	VE218	VE318
	1	1	1	1	1	1	1	1	1	1
	2	3	3	8	8	8	8	8	8	8
M20	3	2	4	10	14	14	14	8	8	8
M25		2	2	2	4	10	10	10	14	18
M32		1	1	1	1	2	2	1	1	2
				1	1	1	1	1	1	1



	VE103	VE106	VE110
A (mm)	120	126	136
B (mm)		108	180

