

Pulse/Freq/Quad (4chan, 1Quad)	900K01-0201	Can be used in Safety systems on the Process Worksheet ONLY.
Safety Universal Input/ Output	900U02-0100	Yes
Low Voltage Terminal Block (Euro style)	900TEK-0200	Yes
Low Voltage Terminal Block (Barrier style)	900TBK-0200	Yes
High Voltage Terminal Block (Euro style)	900TER-0200	Yes
High Voltage Terminal Block (Barrier style)	900TBR-0200	Yes
High Density Terminal Block (Euro style)	900TCK-0200	Yes
Filler Block Terminal Cover	900TNF-0200	Yes
Analog Input Remote Terminal Panel (RTP)	900RTA-L001	No
Relay Output Remote Terminal Panel (RTP)	900RTR-H001	No
DI, DO, AO Remote Terminal Panel (RTP)	900RTS-0001	No
Redundant UIO Remote Terminal Panel	900RTI-0100	Yes
Power Supplies		
120/240 VAC. 60W	900P01-0401	Yes
Redundant Power status module	900PSM-0200	Yes
Redundant Switch module	900RSM-0200	Yes

*Reference only – For the latest Hardware and firmware revision numbers can be found at: https://www.honeywellprocess.com/library/support/Public/Downloads/ControlEdge_HC900-SafetyControllerModulesRevisions.zip

Conventions

Throughout this guide, where the text “Legacy systems” is used, the following model numbers are applicable.

- Legacy systems Model Numbers
 - 900C51 – 00XX-00
 - 900C52 – 00XX-00
 - 900C31 – 00XX-00
 - 900C32 – 00XX-00
 - 900C71 – 00XX-00
 - 900C72 – 00XX-00
 - 900C71R – 0000-XX
 - 900C72R – 0000-XX
 - 900RSM – 0001
 - 900C73R – 0000-XX
 - 900C53 – 00XX-00

Throughout this guide, where the text “New systems” is used, the following model numbers are applicable.

Note: Model number change: 900*xx where if *= C designates Controller module and *=S designates