

Model number

VAA-2E2A-KE1P-S/E2


KE1-Safety module for the control cabinet


2 safety-related inputs and 2 conventional electronic outputs

Features


- 2 safe inputs for mechanical contacts such as EMERGENCY-STOP switch
- Housing with removable terminals
- · Communication monitoring
- Power supply of outputs from the external auxiliary voltage
- Power supply of inputs from the module
- Function display for bus, ext. auxiliary voltage, inputs and outputs
- · Output overload monitoring
- Switchable internal logic operation of the inputs and outputs via parameter bit
- · Addressing jack

Dimensions






Electrical connection



Indicating / Operating means



Technical data		
General specifications		
Slave type		Safety-Slave
AS-Interface specification		V2.1
Required master specification		≥ V2.1
UL File Number		E223772
Functional safety related parame	eters	
Safety Integrity Level (SIL)		SIL 3
Performance level (PL)		PL e
MTTF _d		200 a
PFH _d		0
PFD		0
Indicators/operating means		
LED FAULT		error display; LED red red: communication error or address is 0 red flashing: Output supply overload
LED PWR		AS-Interface voltage; LED green
LED AUX		ext. auxiliary voltage U _{AUX} ; LED green
LED IN		switching state (input); 2 LED yellow
LED OUT		Switching state (output); 2 LED yellow
Electrical specifications		
Auxiliary voltage (output)	U_{AUX}	20 30 V DC PELV
Rated operating voltage	U _e	26.5 31.6 V from AS-Interface
Rated operating current	l _e	≤ 70 mA
Protection class		III
Surge protection		$\textbf{U}_{AUX},\textbf{U}_{e}\text{:}$ overvoltage category II, safe isolated power supplies (PELV)
Input		
Number/Type		2 safety-related inputs for mechanical contacts, crossed-circuit monitored: 2 single-channel contacts: up to category 2/PL c to ISO 13849-1 or 1 2-channel contact: up to category 4/PL e to ISO 13849-1 Cable length must not exceed 300 m per input.
Supply		from AS-Interface
Voltage		20 30 V DC pulsed
Current loading capacity		input current limited ≤ 15 mA, overload and short-circuit resistant
Output		
Number/Type		2 conventional electronic outputs, PNP
Supply		from external auxiliary voltage U _{AUX}
Voltage		≥ (U _{AUX} - 0.5 V)
Current		0.5 A per output
Directive conformity		
Electromagnetic compatibility		
Directive 2014/30/EU		EN 62026-2:2013 EN 61496-1:2004
Standard conformity		
Insulation coordination		EN 50178:1998
Electromagnetic compatibility		EN 61000-6-2:2005, EN 61000-4-5:2005 1 kV asymmetric, criterion B, EN 61000-6-4:2007
Degree of protection		EN 60529:2000

Function

The VAA-2E2A-KE1-S/E2 is an AS-Interface safety module with 2 safety-related inputs and 2 conventional outputs. A dual channel mechanical switch or in each case a single channel mechanical switch can be connected to the two safety-related inputs. The outputs are conventional electronic outputs, which may be loaded in total with 1 A (max. 0,5 A per output).

The housing, only 22.5 mm in width and 48.5 mm in height, takes up little place in the switch cabinet. The module features an integrated addressing jack is mounted by snapping onto the 35 mm DIN rail in accordance with EN 50022. Plug-in terminals are used for connection. A 4-way terminal block (black) is used for the inputs. The AS-Interface is connected via a double terminal block (yellow).

The current switching state of each channel is indicated by an LED, located on the module's top side. Similarly, an LED is provided to monitor the AS-Interface communication and to indicate that the module has the address 0. If a communication error occurs, the outputs are de-energized (only P0=1).

When single channel force-directed mechanical switches are connected, up to Performance level c in accordance with EN ISO 13849-1 can be achieved, given the appropriate wiring and selection of switch.

When a two-channel force-directed mechanical switch is connected, up to Performance level e in accordance with EN ISO 13849-1 can be achieved, given the appropriate wiring and selection of switch.

As per approval in accordance with IEC 61508 and IEC 62061 up to SIL 3 can be

Both inputs of the module are assigned. The two channels of the mechanical switch are monitored for a cross circuit. LEDs are also provided to indicate AS-Interface voltage and external power supply.

Accessories

VBP-HH1-V3.0-KIT

AS-Interface Handheld with accessory

VBP-HH1-V3.0

AS-Interface Handheld

VAZ-PK-1,5M-V1-G

Adapter cable module/hand-held programming device

PEPPERL+FUCHS

Fieldbus standard

Electrical safety

EN 62026-2:2013

EN 50178:1998 IEC 60204-1:2007

Emitted interference	EN 61000-6-4:2007		
AS-Interface	EN 62026-2:2013		
Functional safety	EN ISO 13849-1:2015 up to PL e, IEC 61508:2010 and IEC 62061:2005/A2:2015 up to SIL 3		
Standards	NFPA 79:2002		
Programming instructions			
Profile	S-7.B		
IO code	7		
ID code	В		
ID1 code	F		
ID2 code	0		
Data bits (function via AS-Interface)	input	output	
D0	dyn. safety code 1	OUT 1	
D1	dyn. safety code 1	OUT 2	
D2	dyn. safety code 2	-	
D3	dyn. safety code 2	-	
Parameter bits (programmable via AS-i)	function		
P0	Logic operation: P0 = 1 (default settings): The outputs are controlled via AS-Interface. P0 = 0: The outputs are controlled via AS-Interface or the inputs. The corresponding output is activated on opening the contacts of an input.		
P1	not used		
P2	not used		
P3	not used		
Ambient conditions			
Ambient temperature	-25 50 °C (-13 122 °F)		
Storage temperature	-25 85 °C (-13 185 °F)		
Relative humidity	85 % , noncondensing		
Climatic conditions	For indoor use only		
Altitude	≤ 2000 m above MSL		
Shock and impact resistance	10 g, 16 ms in 6 spatial directions 1000 shocks		
Vibration resistance	0.75 mm 10 57 Hz , 5 g 57 150 Hz, 20 cycles		
Pollution degree	2		
Mechanical specifications			
Degree of protection	IP20		
Connection	removable spring terminals Conductor cross-section 0,25 2,5 mm ²		
Material			
Housing	PA 66-FR		
Mass	80 g		
Mounting	DIN mounting rail		
Tightening torque of clamping screws	0.5 Nm 0.6 Nm		

Notes

The cables and the laying of the cables have to meet the standards which apply to the particular application, e.g. IEC 60204. The instructions for the intended use, the selection and the correct connection of the sensors/actuators or the selection and the attainment of the corresponding safety category are given in the manual.

The outputs may not be used for safety-related functions!

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.